



MIDEA Microwave Oven Operating Instructions



Microwave/Grill/Combi



Weight/Time Defrost



Clock/Timer



Stop/Cancel



Start/+30 sec. / Confirm



Auto menu




Time




Weight

Weight/Time Defrost

- 1) Press Weight/Time Defrost once, and the display will show “dEFI”.
- 2) Turn “”, to select the product weight within the range from 100 to 2,000 grams.
- 3) Press “Start/+30 sec./Confirm”, to start defrosting.

Quick start

- 1) Press Start/+30 sec./ Confirm in the standby mode to start cooking with 100% power, every additional pressing of this button will add 30 seconds to the cooking time, up to the maximum value of 95 minutes.
- 2) In the preheat or defrost mode, every additional pressing of Start/+30 sec./Confirm will increase the cooking time by 30 seconds.
- 3) In the standby mode, turn the “” to the left to set the cooking time to 100% power, then press Start/+30 sec./Confirm to start cooking.